

iTEMPO™ CONTROLS

Dimensional Information for the Round and Square iTempo™ and iTempo/Plus™

BOX CONTENTS:

- iTempo™ or iTempo/Plus™ Control
- Control Cable (30 ft.)
- Steam head
- Tube of Silicone Sealant
- Owner's Manual

iTempo® controls flush mount in the steam/shower enclosure through a 2⁵/₈" wide x 3³/₈" high hole. iTempo controls can also be surface mounted. They are suitable for use with an available iGenie® control. All iTempo controls come standard with solid brass covers in round or square designs. Available in the most popular designer finishes or custom plated as listed below.

iTempo® controls are suitable for use inside or outside the steam/shower enclosure, featuring:

- Solid brass decorative cover with choice of square or round styles in designer finishes
- Digital display for temperature setting
- Programmable temperature
- Includes AromaSteam steamhead in matching finish
- Compatible with iGenie®
- Soft touch keypad with ON/OFF modes
- Low voltage operation


The iTempo controls are designed to be installed inside or outside the steam room but is primarily installed inside the steam room. If the control is installed inside the steam room the control must be located:

- 4-5 feet above the floor
- The control features an integral temperature sensor. Locate the control in a location representative of the desired steam bathing temperatures. Do not locate the control above or near the steam head or direct steam emissions.
- on a vertical wall

The control cable length is 30 feet. Insure that the control and/or steam generator are located accordingly. Contact a Mr.Steam technical service representative if a longer cable is required. Contact Mr.Steam for optional

60 ft. cable, PN 103990-60. If the control is installed outside the steam room a Remote Temperature Probe Part Number MSTS must be installed inside the steam room.

iTEMPO/Plus Controls are available in the following designer finishes: Polished Chrome, Polished Nickel, Brushed Nickel, Polished Brass, Oil Rubbed Bronze and Custom Plating.



NOTE: FOR ILLUSTRATIVE PURPOSES ONLY

IMPORTANT: See Mr.Steam® Installation, Operation and Maintenance Manual, PUR 100472, for details.

Click here to download this manual:

<http://www.mrsteam.com/support/downloads.html>